

# Rack Conveyor Dishwasher WT 140 Model




Operator to wear PVC or disposable apron and gloves when cleaning the machine.



## DAILY


1

**Isolate** from the electrical supply. Empty the machine and **allow to cool**. **Pull out the drain plugs** upwards to empty the wash and rinse tanks.




2

**Remove the wash tank arms** by rotating holding clips 90°. Care must be taken to not loosen or damage any parts. **Check that the spray nozzles and arm end caps are securely in place.** **Note that the washer will not function correctly if any are missing or damaged. If any missing or damaged then report to department manager.** **Clean** the removed arms using a scourer and **M1** Cleaning Detergent solution. Use a non-metallic implement to dislodge or prise out any material clogging the jets.




3

**Remove the rinse arms** from their spring plates and check that the jets are clear. **Clean** the removed arms using a designated brush and **M1** Cleaning Detergent solution.



4

**Unhook the strip curtains** from either end of the dishwasher. **Remove filters and plugs** and clean with **M1** Cleaning Detergent. **Clean** the curtains using a scourer and **M1** Cleaning Detergent solution.



5

Using cloth and **M1** Cleaning Detergent solution clean all **internal and external surfaces** of the dishwasher, ensure backs of doors, water holding tanks and hard to reach areas are cleaned. Replace all cleaned removed parts. **Spray all internal surfaces with M2 Sanitiser solution, leave doors up** and allow all internal surfaces to air dry.

